

DUAL SPEED PTO SETUP INSTRUCTIONS




8" groove inside
(540 RPM gearing)

10" groove outside
(1000 RPM gearing)

Pulley 8/10 x 1C

Side Shaft Pulley



10" groove outside
(540 RPM gearing)

12" groove inside
(1000 RPM gearing)

Pulley 10/12 x 1C

PTO Shaft Pulley



Ensure the vee belt is aligned with
the drive pulleys and idlers.

Outside setting : 1000 RPM

Inside Setting : 540 RPM